SCF353A

30cm BOX FAN

USER GUIDE

sunstech

CONTENT

PARTS LIST 1
OPERATING INSTRUCTIONS 2
CLEANING, CARE AND MAINTENANCE 4
SPECIFICATION TABLE 4
SAFETY INSTRUCTIONS 5

PARTS LIST

OPERATING INSTRUCTIONS

NOTE: Please ensure you place the Fan on a stable, dry level surface to avoid tipping over.

1. Plug in the power cord of the electrical outlet and switch on.
2. To commence operation, adjust the speed setting (Hot accordingly. Speed:
   0 = Off
   1 = Low.
   2 = Medium
   3 = High
3. To activate oscillation function, set the slider switch to "MANUAL".

4. To activate the timer, rotate the dial to a point beyond time setting.

5. The direction of the airflow can be adjusted by tilting the fan forwards/backwards.
6. To stop the fan, rotate the Speed dial to "0" position.

NOTE: For optimal airflow, do not place fan against curtains or near a wall.

CLEANING, CARE AND MAINTENANCE

Be sure the Box Fan is switched off and the plug removed from the socket before cleaning.

1. To clean the exterior of the fan, wipe over the surface with a damp cloth and then dry with a soft cloth or tissue.
2. You can also use a vacuum cleaner to remove light dust from the grille.
3. Do not use detergents or abrasive cleaners, and do not allow water to enter the Fan.

SPECIFICATION TABLE

MODEL:	SCF353A
POWER SUPPLY:	50~ 230V 200W
VOLTAGE:	220-240V, 50Hz

SAFETY INSTRUCTIONS

Please take the user manual in a safe place along with your purchase receipt and warranty card. Please read the following safety instructions here to reduce the risk of fire, electric shock and injury when carrying out any operation.

Grille Blades of the Fan

Safety Guard & Rear Grille

Your product is designed and manufactured with high quality materials and components which can be recycled and reused.

This symbol means that electrical and electronic equipment, at their end of life should be disposed of separately from your household waste. Please, do not dispose this product as unsorted municipal waste.

Please dispose of this equipment at your local community waste collection/recycling centre.

In the European Union there are separate collection systems for used electrical and electronic products. Please help us to conserve the environment we live in!

DO NOT place objects or any of the device, as blades may scratch this surface.

DO NOT insert the device in areas of water environments.

DO NOT place the device near or on a heat source.

DO NOT place the device near or on a cooker or surface.

DO NOT insert any foreign objects into the device.

DO NOT cover the device in a bag, together or otherwise fabric.

DO NOT operate if blades, guards or rear/front grilles are damaged or missing.

DO NOT expose the device to direct sunlight or a non-damage the device, leave it in a hot environment.

DO NOT place your device in transportation regions that will subject it to unsafe operating environments that exceed a Pollution Degree 2 or lower.

DO NOT use the device in the rain.

Always check with your local authority or retailer for proper disposal of electronic products.

The device and adapter may produce some heat during normal operation. Please ensure there is adequate space around the device and adapter to prevent any damage.

Avoid direct damage. Refer to the rating plate on the device and ensure that the power supply is suitable for your local mains voltage.

Avoid the device and it's cable if it shows signs of damage. Contact the manufacturer or a qualified technician for repairs.

Do not remove the device from an electrical socket when power off before cleaning.

Disconnect the device from an electrical socket and power off before cleaning.

Disconnect the device, allow it to cool before attempt technical maintenance.

Ensure the power cord is not trapped or kink, do NOT place the device on the cord, heat sources or sharp edges.

Do not operate if exposed to moisture or excessive heat. Dispose of damaged or faulty equipment in a safe manner.

Ensure the power cord is not damaged and that the outlet socket has the correct voltage and is fully accessible.

Energuide Energy Consumption Information

This system meets the Canadian Energy Efficiency Regulations and complies with the Energy Star requirements. Energy Star is a voluntary program that promotes energy efficiency through the use of efficient products and practices. Use of Energy Star products and services can save you money and reduce greenhouse gas emissions. For more information, visit the Energy Star website at www.energystar.gov.

Model: SCF353A

SCF353A

VENTILADOR 30cm

GUÍA DE USUARIO

sunstech

CONTENIDO

LISTA DE COMPONENTES 1
INSTRUCCIONES DE FUNCIONAMIENTO 2
LIMPIEZA Y MANTENIMIENTO 4
TABLA DE ESPECIFICACIONES 4
INSTRUCCIONES DE SEGURIDAD 5

LISTA DE COMPONENTES

INSTRUCCIONES DE FUNCIONAMIENTO

NOTA: Asegúrese de que el ventilador se encuentre en una superficie plana, estable y seca, para evitar que se vuelque.

1. Conecte el cable de alimentación al enchufe eléctrico y encienda.
2. Para comenzar el funcionamiento, ajuste el ventilador (Hot según la configuración de velocidad. Velocidad:
   0 = Desp
   1 = Bajo.
   2 = Medio
   3 = Alto
3. Para activar la oscilación de la rejilla, ajuste el interruptor LOCKED a "MANUAL".

4. Para activar el temporizador, gire el dial hasta un tiempo deseado.

5. La dirección del flujo de aire se puede ajustar inclinando el ventilador hacia delante/atrás.
6. Para detener el ventilador, gire el dial de Velocidad hasta "0".

NOTA: Para lograr un flujo de aire, no coloque el ventilador cerca de cortinas o paredes.

LIMPIEZA Y MANTENIMIENTO

Antes de limpiar, asegúrese de que el ventilador está desconectado y de que se ha retirado el enchufe de la toma de corriente.

1. Para limpiar el exterior del ventilador, limpie la superficie con un paño humedecido y luego séquelo con un paño seco o suave.
2. También puede usar una aspiradora para retirar el polvo de la rejilla.
3. No utilice productos abrasivos o detergentes, y no permita que entre agua en el ventilador.

TABLA DE ESPECIFICACIONES

MODELO:	SCF353A
FUENTE DE ALIMENTACIÓN:	50~ 230V 200W
VOLTAJE:	220-240V, 50Hz

INSTRUCCIONES DE SEGURIDAD

Tome nota de su manual de instrucciones junto con su recibo de compra y su tarjeta de garantía. Lea las siguientes instrucciones de seguridad antes de llevar a cabo cualquier operación para reducir el riesgo de incendio, descarga eléctrica y lesiones.

Rejillas delantera y trasera del ventilador

Protección delantera y alrededores del ventilador

La protección de este dispositivo fabricado con materiales de alta calidad y componentes que pueden reciclarse y reutilizarse.

Este símbolo indica que el ciclo de vida de los equipos eléctricos y electrónicos deben ser desechados por separado y no debe ser desechado como residuo municipal.

Por favor, deseche este equipo en su centro de recogida/reciclaje local.

En la Unión Europea hay sistemas de recogida específicos para los productos electrónicos y eléctricos usados. Ayude a conservar el medio ambiente en el que vivimos!

No coloque objetos encima del aparato/ejemplo: cuerpo.

No coloque el aparato en ambientes acuosos.

No coloque el aparato cerca o en una fuente de calor/una fuente.

No coloque ningún objeto extraño en el aparato.

No cubra el aparato con una bolsa o tejido/tela o cualquier tipo de tela.

No opere si las aspas, rejillas delantera/trasera o rejillas traseras/frontales están dañadas o faltan.

No exponga el aparato a la luz directa del sol o a un daño no dañe el dispositivo, déjelo en un entorno caliente.

No utilice el aparato bajo lluvia.

Consulte con su proveedor/autoridad o utilizado para evitar eléctrico de forma segura de productos electrónicos.

El aparato y su adaptador pueden producir algo de calor durante el funcionamiento normal. Asegúrese de que hay suficiente espacio alrededor del aparato y del adaptador para evitar cualquier daño.

Evite daños directos. Consulte la placa de características del aparato y asegúrese de que la fuente de alimentación sea adecuada para la tensión de su red local.

Evite el aparato y su cable si muestran signos de daños. Contáctese con el fabricante o un técnico cualificado para reparaciones.

Desconecte el aparato de la toma de corriente eléctrica y apagado antes de limpiarlo.

Desconecte el aparato de la toma de corriente eléctrica y apagado antes de limpiarlo.

Desconecte el aparato, déjelo que se enfríe y asegúrese de que el cable de alimentación no se pliegue.

El aparato debe operar para fuera como: del interior de ambiente húmedo o bajo condiciones de calor excesivo. Deseche el equipo dañado o defectuoso de forma segura.

Asegúrese de que el cable de alimentación no se pliegue o enfrenta/se encuentra dentro de la toma de corriente y es accesible.

Energuide Europeo información sobre energía

El sistema cumple con los requisitos de la normativa Energuide. La protección que ofrece Energuide es voluntaria. Energuide es un programa que promueve la eficiencia energética a través del uso de productos y prácticas eficientes. El uso de productos y servicios Energuide puede ahorrar dinero y reducir las emisiones de gases de efecto invernadero. Para más información, visite el sitio web de Energuide en www.energuide.com.

Modelo: SCF353A

sunstech

For you. For everyone.